

1) Put on the side glasses and screw them on



2) Fix the light support on the acrylic supports located on the side glasses.



3) Fix the upper structure where the frontal glass will lay.



4) Bend the frontal glass until it lays on the upper support



5) If you have 2 cabinets with 2 frontal glasses, you'll need to align them.

For this you only need to push a bit forward the glass that badly lays on the upper support.

